

ABBREVIATIONS

ABC123

Entire Article
2000 Chevrolet Camaro

ARTICLE BEGINNING

GENERAL INFORMATION

COMMONLY USED ABBREVIATION

"A" ABBREVIATION TABLE

"A" ABBREVIATION TABLE

Table with 3 columns: Abbreviation, Definition, and Page Number. Rows include: ABBREVIATION DEFINITION 3, A Amperes 3, A/C Air Conditioning 3, A/T Automatic Transmission/Transaxle 3, AAP Auxiliary Accelerator Pump 3, AB Air Bleed 3, ABCV Air Bleed Control Valve 3, ABDC After Bottom Dead Center 3, ABRS Air Bag Restraint System 3, ABS Anti-Lock Brake System 3, AC Alternating Current 3, ACC A/C Clutch Compressor 3, ACCS A/C Cycling Switch 3, ACCUM Accumulator 3, ACCY Accessory 3, ACT Air Charge Temperature Sensor 3, ACV Thermactor Air Control Valve 3, ADJ Adjust or Adjustable 3, ADV Advance 3, AFS Airflow Sensor 3, AI Air Injection 3, AIR or A.I.R. Air Injection Reactor 3, AIS Air Injection System 3, ALCL Assembly Line Communications Link 3, ALDL Assembly Line Diagnostic Link 3, ARC Automatic Ride Control 3, ASCD Automatic Speed Control Device 3, ASCS Air Suction Control Solenoid 3, ASD Auto Shutdown 3, ASDM Air Bag System Diagnostic Module 3, ASV Air Suction Valve 3, ATC Automatic Temperature Control 3, ATDC After Top Dead Center 3, ATF Automatic Transmission Fluid 3, ATS Air Temperature Sensor 3, AXOD Automatic Transaxle Overdrive 3, Abs. Absolute 3, Accy. Accessory 3, Alt. Alternator or Altitude 3, Amp. Ampere 3, Assy. Assembly 3, Auto. Automatic 3

ABBREVIATIONS

ABC123

Entire Article
2000 Chevrolet Camaro

3Aux. 3Auxiliary 3
3Avg. 3Average 3
AAUU

"B" ABBREVIATION TABLE

" B" ABBREVIATION TABLE
UAAU
3ABBREVIATION 3DEFINITION 3
AA
3B/P 3Backpressure 3
3BAC 3By-Pass Air Control 3
3BAP 3Barometric Absolute Pressure Sensor 3
3BARO 3Barometric 3
3BBDC 3Before Bottom Dead Center 3
3BCM 3Body Control Module 3
3BDC 3Bottom Dead Center 3
3BHP 3Brake Horsepower 3
3BLK 3Black 3
3BLU 3Blue 3
3BMAP 3Barometric & Manifold Absolute Pressure Sensor 3
3B00 3Brake On-Off Switch 3
3BP 3Barometric Pressure sensor 3
3BPS 3Barometric Pressure Sensor 3
3BPT 3Backpressure Transducer 3
3BRN 3Brown 3
3BTDC 3Before Top Dead Center 3
3BTU 3British Thermal Unit 3
3BVSV 3Bi metallic Vacuum Switching Valve 3
3Baro. 3Barometric 3
3Batt. 3Battery 3
3Bbl. 3Barrel (Example: 4-Bbl.) 3
3Blst. 3Ballast 3
3Blwr. 3Blower 3
3Brkr. 3Breaker 3
AAUU

"C" ABBREVIATION TABLE

" C" ABBREVIATION TABLE
UAAU
3ABBREVIATION 3DEFINITION 3
AA
3ø C 3Celsius (Degrees) 3
3C(3) I 3Computer Controlled Coil Ignition 3
3C(4) 3Computer Controlled Catalytic Converter 3
3CANP 3Canister Purge solenoid 3
3CARB 3California Air Resources Board 3
3CAT 3Catalytic Converter 3
3CB 3Circuit Breaker 3
3CBD 3Closed Bowl Distributor 3
3CBVV 3Carburetor Bowl Vent Valve 3
3cc 3Cubic Centimeter 3

ABBREVIATIONS

ABC123

Entire Article
2000 Chevrolet Camaro

³CCC	³Computer Command Control	3
³CCD	³Computer Controlled Dwell	3
³CCM	³Central Control Module	3
³CCO	³Converter Clutch Override	3
³CCOT	³Cycling Clutch Orifice Tube	3
³CCW	³Counter-clockwise	3
³CDI	³Capacitor Discharge Ignition	3
³CEC	³Computerized Engine Control	3
³CFI	³Central Fuel Injection	3
³CID	³Cubic Inch Displacement	3
³CID	³Cylinder Identification sensor	3
³CIS	³Continuous Injection System	3
³CIS-E	³Continuous Injection System-Electronic	3
³CKT	³Circuit	3
³CLR	³Clear	3
³CNG	³Compressed Natural Gas	3
³CO	³Carbon Monoxide	3
³CO2	³Carbon Dioxide	3
³CONV	³Convertible	3
³CP	³Canister Purge	3
³CPA	³Connector Position Assurance	3
³CPS	³Crank Position Sensor	3
³CTS	³Coolant Temperature Sensor	3
³CV	³Check Valve or Constant Velocity	3
³CVC	³Constant Vacuum Control	3
³CW	³Clockwise	3
³CYL or Cyl.	³Cylinder	3
³Calif.	³California	3
³Carb.	³Carburetor	3
³Chrg.	³Charging	3
³Circ.	³Circuit	3
³Cntrl.	³Control	3
³Comp.	³Compressor or Compartment	3
³Conn.	³Connector	3
³Cont.	³Continued	3
³Conv.	³Convertible or Converter	3
³Cu. In.	³Cubic Inch	3
³Cyl.	³Cylinder	3
AAUU		

"D" ABBREVIATION TABLE

"D" ABBREVIATION TABLE
 UAAU
 ³ABBREVIATION ³DEFINITION 3
 AA
 ³"D" ³Drive 3
 ³DBC ³Dual Bed Catalyst 3
 ³DC ³Direct Current or Discharge 3
 ³DDD ³Dual Diaphragm Distributor 3
 ³DERM ³Diagnostic Energy Reserve Module 3
 ³DFI ³Digital Fuel Injection 3
 ³DIC ³Driver Information Center 3
 ³DIS ³Direct Ignition System 3

ABBREVIATIONS

ABC123

Entire Article
2000 Chevrolet Camaro

³DIS	³Distributorless Ignition System	3
³DIST	³Distribution	3
³DISTR	³Distributor	3
³DK BLU	³Dark Blue	3
³DK GRN	³Dark Green	3
³DME	³Digital Motor Electronics (Motronic System)	3
³DOHC	³Double Overhead Cam	3
³DOT	³Department of Transportation	3
³DP	³Dashpot	3
³DRB-11	³Diagnostic Readout Box	3
³DVOM	³Digital Volt/Ohm Meter (see VOM)	3
³Def.	³Defogger or Defroster	3
³Def.	³Defrost	3
³Defog.	³Defogger	3
³Diag.	³Diagnostic	3
³Dist.	³Distributor or Distribution	3
³Dr.	³Door	3
AAUU		

"E" ABBREVIATION TABLE

"E" ABBREVIATION TABLE
 UAAU

³ABBREVIATION	³DEFINITION	3
AA		
³EAC	³Electric Assist Choke	3
³EACV	³Electric Air Control Valve	3
³EBCM	³Electronic Brake Control Module	3
³ECA	³Electronic Control Assembly	3
³ECAT	³Electronically Controlled Automatic Transaxle	3
³ECM	³Electronic Control Module	3
³ECT	³Engine Coolant Temperature Sensor	3
³ECU	³Electronic Control Unit or Engine Control Unit	3
³EDF	³Electric Drive Fan relay assembly	3
³EDIS	³Electronic Distributorless Ignition System	3
³EEC	³Electronic Engine Control	3
³EECS	³Evaporative Emission Control System	3
³EEPROM	³Electronically Erasable PROM	3
³EFE	³Early Fuel Evaporation	3
³EFI	³Electronic Fuel Injection	3
³EGO	³Exhaust Gas Oxygen sensor (see HEGO)	3
³EGR	³Exhaust Gas Recirculation system	3
³EGRC	³EGR Control solenoid or system	3
³EGRV	³EGR Vent solenoid or system	3
³EMR	³Emission Maintenance Reminder Module	3
³ESA	³Electronic Spark Advance	3
³ESC	³Electronic Spark Control	3
³EST	³Electronic Spark Timing	3
³ETR	³Emergency Tensioning Retractor	3
³EVAP	³Fuel Evaporative System	3
³EVIC	³Electronic Vehicle Information Center	3
³EVO	³Electronic Variable Orifice	3
³EVP	³EGR Valve Position Sensor	3
³EVR	³EGR Valve Regulator	3

ABBREVIATIONS

ABC123

Entire Article
2000 Chevrolet Camaro

3EVRV 3Electroni c Vacuum Regul ator Valve 3
3El ect. 3El ectroni c 3
3Eng. 3Engi ne 3
3Evap. 3Evaporati ve 3
3Exc. 3Except 3
AAUU

"F" ABBREVIATION TABLE

" F" ABBREVI ATI ON TABLE
UAAUU
3ABBREVI ATI ON 3DEFI NI TI ON 3
AAU
3ø F 3Fahrenhei t (Degrees) 3
3F/B 3Fuse Bl ock 3
3FBC 3Feedba ck Carburetor 3
3FI 3Fuel Inj ector or Fuel Inj ecti on 3
3FI CD 3Fast Idl e Control Devi ce 3
3FI PL 3Fuel Inj ector Pump Lever 3
3FP 3Fuel Pump 3
3FPM 3Fuel Pump Moni tor 3
3FPR-VSV 3Fuel Pressure Regul ator Vacuum Swi tchi ng Valve 3
3FWD 3Front Wheel Dri ve 3
3Fed. 3Federal 3
3Ft. Lbs. 3Foot Pounds 3
AAUU

"G" ABBREVIATION TABLE

" G" ABBREVI ATI ON TABLE
UAAUU
3ABBREVI ATI ON 3DEFI NI TI ON 3
AAU
3g 3grams 3
3GND or GRND 3Ground 3
3GRN 3Green 3
3GRY 3Gray 3
3Ga. 3Gauge 3
3Gal s. 3gal lons 3
3Gov. 3Governor 3
AAUU

"H" ABBREVIATION TABLE

" H" ABBREVI ATI ON TABLE
UAAUU
3ABBREVI ATI ON 3DEFI NI TI ON 3
AAU
3H/D 3Heavy Duty 3
3HAC 3Hi gh Al ti tude Compensati on 3
3HC 3Hydrocarbons 3
3HEDF 3Hi gh Speed El ectro Dri ve Fan relay or ci rcui t 3
3HEGO 3Heated Exhaust Gas Oxygen Sensor 3

ABBREVIATIONS

ABC123

Entire Article
2000 Chevrolet Camaro

Table with 3 columns: Abbreviation, Definition, and Page Number. Includes entries for HEGOG, HEI, HLDT, HO, HP, HSC, HSO, HTR, HVAC, Headl t., Hg, Hgt., Htr., and Hz.

"I" ABBREVIATION TABLE

"I" ABBREVIATION TABLE
Table with 3 columns: Abbreviation, Definition, and Page Number. Includes entries for I.D., IAC, IACV, IC, ID, IDM, IGN, ILC, In. Hg, INCH Lbs., INFL REST, INJ, IP, IPC, ISA, ISC, ISS, ITS, IVSV, Ign., In., and Inj.

"J" ABBREVIATION TABLE

"J" ABBREVIATION TABLE
Table with 3 columns: Abbreviation, Definition, and Page Number. Includes entry for J/B.

ABBREVIATIONS

ABC123

Entire Article
2000 Chevrolet Camaro

AAUU

"K" ABBREVIATION TABLE

"K" ABBREVIATION TABLE

AAUU

ABBREVIATION	DEFINITION	
AAA	AAA	'
k/ohms	1000 ohms (kilo as in k/ohms)	3
kg	Kilograms (weight)	3
kg/cm ²	Kilograms Per Square Centimeter	3
KAM	Keep Alive Memory	3
KAPWR	Keep Alive Power	3
KM/H	Kilometers Per Hour	3
KOEO	Key On Engine Off	3
KOER	Key On Engine Runni ng	3
KS	Knock Sensor	3

AAUU

"L" ABBREVIATION TABLE

"L" ABBREVIATION TABLE

AAUU

ABBREVIATION	DEFINITION	
AAA	AAA	'
L	Li ter(s)	3
L/D	Li ght Duty	3
LCD	Li qui d Crystal Di spl ay	3
LED	Li ght Emi tti ng Di ode	3
LH	Left Hand	3
LOS	Li mi ted Operati on Strategy	3
LT BLU	Li ght Blue	3
LT GRN	Li ght Green	3
LUS	Lock-Up Sol enoi d	3
Lbs.	Pounds	3
Lt(s).	Li ght(s)	3
Lugg.	Luggage	3

AAUU

"M" ABBREVIATION TABLE

"M" ABBREVIATION TABLE

AAUU

ABBREVIATION	DEFINITION	
AAA	AAA	'
mA	Milli amps	3
mV	Milli volts	3
mfd.	Microfarads	3
mm	Millimeters	3
M/T	Manual Transaxle or Transmi ssi on	3
MA PFI	Mass Air Sequential Port Fuel Injecti on system	3
MA or MAF	Mass Air flow	3
MAF	Mass Air Flow sensor	3

ABBREVIATIONS

ABC123

Entire Article
2000 Chevrolet Camaro

3MAFS 3Mass Airflow Sensor 3
3MAP 3Manifold Absolute Pressure sensor 3
3MAT 3Manifold Air Temperature 3
3MCU 3Microprocessor Control Unit 3
3MCV 3Mixture Control Valve 3
3MEM-CAL 3Memory Calibration Chip 3
3MFI 3Multiport Fuel Injection 3
3MIL 3Malfunction Indicator Light 3
3MLP 3Manual Lever Position 3
3MPFI 3Multi Point Fuel Injection 3
3MPH 3Miles Per Hour 3
3MPI 3Multi-Point (Fuel) Injection 3
3Man. 3Manual 3
3Mech. 3Mechanical 3
3Mem. 3Memory 3
3Mtr. 3Motor 3
AAU

"N" ABBREVIATION TABLE

"N" ABBREVIATION TABLE
UAAU
3ABBREVIATION 3DEFINITION 3
AAU
3N. m 3Newton-Meter 3
3NA 3Not Available 3
3NDS 3Neutral Drive Switch 3
3NGS 3Neutral Gear Switch 3
3NOx 3Oxides of Nitrogen 3
3NPS 3Neutral Pressure Switch 3
3No. 3Number 3
3Nos. 3Numbers 3
AAU

"O" ABBREVIATION TABLE

"O" ABBREVIATION TABLE
UAAU
3ABBREVIATION 3DEFINITION 3
AAU
3O 3Oxygen 3
3O. D. 3Outside Diameter 3
3O/S 3Oversize 3
3O2 3Oxygen 3
3OC 3Oxidation Catalyst 3
3OCC 3Output Circuit Check 3
3OD 3Overdrive 3
3ODO 3Odometer 3
3OHC 3Overhead Camshaft 3
3ORG 3Orange 3
3OSC 3Output State Check 3
3Opt. 3Option or Optional 3
3oz. 3Ounce 3

ABBREVIATIONS

ABC123

Entire Article
2000 Chevrolet Camaro

3ozs. 3Ounces 3
AAU

"P" ABBREVIATION TABLE

" P" ABBREVIATI ON TABLE
UAAU
3ABBREVIATI ON 3DEFINI TI ON 3
AAU
3" P" 3Park 3
3P/C 3Printed Ci rcui t 3
3P/N 3Park/Neutral 3
3P/S 3Power Steeri ng 3
3PAV 3Pul se Ai r Val ve 3
3PC-SOL 3Purge Control Sol enoi d 3
3PCM 3Powertrain Control Modul e 3
3PCS 3Purge Control Sol enoi d 3
3PCSDM 3Passenger Compartment Sensor/Di agnosti c Modul e 3
3PCV 3Posi tive Crankcase Vent i lati on 3
3PFE 3Pressure Feedback EGR sensor or ci rcui t 3
3PFI 3Port Fuel Inj ecti on (see MA SEFI) 3
3PGM-CARB 3Programmed Carburetor 3
3PGM-FI 3Programmed Fuel Inj ecti on 3
3PI P 3Profi le I gni ti on Pi ckup 3
3PNK 3Pi nk 3
3PPL 3Purpl e 3
3PRNDL 3Park Reverse Neutral Drive Low 3
3PROM 3Programmabl e Read-Only Memory 3
3psi 3Pounds Per Square Inch 3
3PSPS 3Power Steeri ng Pressure Swi tch 3
3PTC 3Posi tive Temperature Coeffi ci ent 3
3PTO 3Power Take-Off 3
3PWR GND 3Power Ground ci rcui t 3
3Pkg. 3Packag e 3
3Press. 3Pressur e 3
3Prog. 3Programmed or Programmabl e 3
3Pts. 3Pi nts 3
3Pwr. 3Power 3
AAU

"Q" ABBREVIATION TABLE

" Q" ABBREVIATI ON TABLE
UAAU
3ABBREVIATI ON 3DEFINI TI ON 3
AAU
3Qts. 3Quarts 3
AAU

"R" ABBREVIATION TABLE

" R" ABBREVIATI ON TABLE
UAAU

ABBREVIATIONS

ABC123

Entire Article
2000 Chevrolet Camaro

³ABBREVIATI ON	³DEFINI TI ON	3
AAA		
³RABS	³Rear Anti -Lock Brake System	3
³RAC	³Remote Accessory Control	3
³RAM	³Random Access Memory	3
³RAP	³Retained Accessory Power	3
³RECI RC	³Reci rcul ati on	3
³RED	³Red	3
³RH	³Right Hand	3
³ROM	³Read Only Memory	3
³RPM	³Revol uti ons Per Mi nute	3
³RVB	³Rear Vacuum Break	3
³RWAL	³Rear Wheel Anti -Lock Brake	3
³RWD	³Rear Wheel Drive	3
³Reci rc.	³Reci rcul ate or Reci rcul ati on	3
³Reg.	³Regul ator	3
³RI y.	³Rel ay	3
AAU		

"S" ABBREVIATION TABLE

"S" ABBREVIATI ON TABLE

UAA

³ABBREVIATI ON	³DEFINI TI ON	3
AAA		
³SAW	³Spark Angl e Word	3
³SBC	³Si ngl e Bed Converter	3
³SBEC	³Si ngl e Board Engi ne Control l er	3
³SC	³Super Charged	3
³SCC	³Spark Control Computer	3
³SCS	³Ai r Sucti on Control Sol enoi d	3
³SDM	³Suppl emental Restrai nt System Di agnosti c Modul e	3
³SDU	³SRS Di agnosti c Uni t	3
³SEN	³Sensor	3
³SES	³Servi ce Engi ne Soon	3
³SFI	³Sequenti al (Port) Fuel Inj ecti on	3
³SIG RTN	³Si gnal Return ci rcui t	3
³SIL	³Shi ft Indi cator Li ght	3
³SIR	³Suppl emental In fl atabl e Restrai nt	3
³SMEC	³Si ngl e Modul e Engi ne Control l er	3
³SOHC	³Si ngl e Overhead Cam	3
³SOL or Sol .	³Sol enoi d	3
³SPFI	³Sequenti al Port Fuel Inj ecti on	3
³SPK	³Spark Control	3
³SPOUT	³Spark Output Si gnal	3
³SRS	³Suppl emental Restrai nt System (Ai r Bag)	3
³SS 3/4-4/3	³Shi ft Sol enoi d ci rcui t	3
³SSI	³Sol id State I gni ti on	3
³STAR	³Sel f-Test Automati c Readout	3
³STI	³Sel f Test Input ci rcui t	3
³STO	³Sel f-Test Output	3
³SUB-02	³Sub Oxygen Sensor	3
³Sen. or Sens.	³Sensor	3
³Sol .	³Sol enoi d	3

ABBREVIATIONS

ABC123

Entire Article
2000 Chevrolet Camaro

3Sprchg. 3Supercharger 3
3Strg. 3Steering 3
3Susp. 3Suspension 3
3Sw. 3Switch 3
3Sys. 3System 3
AAUU

"T" ABBREVIATION TABLE

"T" ABBREVIATION TABLE
UAAU
3ABBREVIATION 3DEFINITION 3
AAA
3T.V. 3Throttle Valve 3
3TAB 3Thermactor Air By-Pass 3
3TAC 3Thermostatic Air Cleaner 3
3TAD 3Thermactor Air Diverter 3
3TAN 3Tan 3
3TBI 3Throttle Body Injection 3
3TCC 3Torque Converter Clutch 3
3TCCS 3Toyota Computer Control System 3
3TDC 3Top Dead Center 3
3TDCL 3Total Diagnostic Communication Link 3
3TFI 3Thick Film Ignition system 3
3TGS 3Top Gear Switch (cancels SIL in top gear) 3
3THERMAC 3Thermostatic Air Cleaner 3
3THS 3Transmission Hydraulic Switch 3
3TP/TPS 3Throttle Position Sensor 3
3TPI 3Tuned Port Injection 3
3TPS 3Throttle Position Sensor/Switch 3
3TS 3Temperature Sensor 3
3TSB 3Technical Service Bulletin 3
3TTS 3Transmission Temperature Switch 3
3TV 3Thermostat Valve 3
3TWC 3Three-Way Catalyst 3
3Temp. 3Temperature 3
3Trans. 3Transaxle/Transmission 3
AAUU

"V" ABBREVIATION TABLE

"V" ABBREVIATION TABLE
UAAU
3ABBREVIATION 3DEFINITION 3
AAA
3V 3Valve 3
3VAF 3Vane Air Flow sensor or circuit 3
3VAPS 3Variable Assist Power Steering 3
3VAT 3Vane Air Temperature 3
3VATS 3Vehicle Anti-Theft System 3
3VBATT 3Vehicle Battery Voltage 3
3VCC 3Viscous Converter Clutch 3
3VIN 3Vehicle Identification Number 3

